

## **HUSHCORE™ Premium™ System Enclosure Installation Guidelines**

1. Lay out and mark area to be enclosed.
2. Locate all floor bases (do not fasten to floor yet). Please note some floor bases may have the column fitting offset from the center of the 6" x 6" plate. Be sure to orient offset baseplates to accommodate floor interferences such as the chiller housekeeping pad.
3. Place columns onto base plates.
4. Pre-assemble roller track into track connectors on floor by sliding roller track through connectors to designated locations. To make sliding roller track into connectors easier, squeeze ends of roller track together as you slide into the end of connector.  
**NOTE:** See the track orientation drawing to appropriately locate open ends of track. Also, a double track system is created by using two pieces of single track held together by a double track connector.
5. Track rails may be shipped in oversized lengths. Refer to the drawings for overall enclosure dimensions and trim track rail lengths as needed.
6. Raise this assembly and slip track connectors onto top of floor columns.
7. Insert roller hooks provided through grommets in each curtain panel. (Note: Due to the thickness of some types of Acoustical Curtain Panels you may need to pry open roller hooks slightly before installing through grommet. Crimp roller hooks tightly to curtain after installing through grommet.)



8. Lift curtain panels up to the open end of the track, feed wheels of roller hooks into track. See drawings for proper panel locations taking care to note which direction panels face to ensure Velcro seals mate properly to adjacent panels. For double track systems also note on which track (inside or outside) each panel should be installed.



9. Adjust hardware as necessary to accommodate curtains. Install self-tapping screws through top of track connectors into track.
10. Install end stops in all open end of track to prevent rollers from running out of track.
11. Anchor base plates to floor.