

HUSHCORE™ Premium™ “OF” System Installation Guidelines

1. Sort tagged panels according to the project specific layout drawing.
2. When securing to the fence – face the quilted side **toward** the noise source. Face the solid vinyl toward cyclone or chain link fencing.
3. Starting in a corner, attach panels using **.50”** wide by **15”** long – 250lb. high tensile strength UV- resistant cable ties (by the installer).
4. Slide cable tie through grommet hole at top of curtain panel and around fence top rail and fasten it on the inside (Note: do not cut off excess cable tie as it will leave a sharp edge. Instead pull the end of the cable tie flat along the face of blanket.



5. Repeat step 4 for all grommet holes at top of the panel.

6. Attach Velcro strip on next panel to the Velcro strip of the panel already attached to fence. (Note, it does not matter whether 'hook' or 'pile' sides of the Velcro face toward or away from the noise source – but ensure that the next panel aligns to the Velcro strip (hook or pile) of the existing panel while also ensuring that the quilted side always faces the noise source).
7. Repeat steps 4-6 until all panels are attached at top.
8. Attachment using the same method may be required at other grommet locations for bottom or intermediate fence rails. See the drawings for more details.
9. For additional strength use 28AWG wire on top and bottom corners.