

HUSHCORE™ Premium™ “SW” System Installation Guidelines

1. Determine the area to be covered. Install with heavy duty vinyl coated polyester facing side facing noise source and the vinyl coated fiberglass cloth facing against the wall.
2. If you choose to, for ease of installation, you may frame over the existing wall with furring strips or other material and attach the HUSH QUILT™ to the furring members.
3. Attachment shall be with self-tapping screws or fasteners appropriate for substrate, or other framing material as dictated by site conditions.



4. Screw directly through the QAB material into the wall or framing material with a fender washer, between the screw and the QAB material.
5. Cutouts to accommodate wall interferences with electrical boxes, conduits, light fixtures, etc. shall be done with the field modification kit usually supplied with the QAB material. Cutouts shall be done as follows.
 1. Cut panels with utility knife or shears to fit as snug as possible. Keep gaps to a minimum.
 2. Fold edge binding material over edges, equal amounts on front and back. (Note: A few staples along cut edge will help compress material prior to installing edge binding.)
 3. Staple bind edge binding material to panel, with staples every 2- 3 inches.